

The List of corresponding USB memories

ADTEC AD-DSS256M, AD-DSS256M/U2 (USB memory)
ADTEC Intelligent Stick 128MB (Ver2.0 disable)

BUFFALO (melco) RUF-C, RUF-C32ML, RUF-C128ML-K/U2,
RUF-C128ML-K/U2, RUF-C256ML/U2 (USB memory)
BUFFALO (melco) MCR-C8/U2 (Multiple card RW)
BUFFALO (melco) RUF-DB-U2 (USB memory)
BUFFALO (melco) MCR-2UX (SmartMedia and CompactFlash RW)
BUFFALO (melco) MCR-SD-LT/U2 (SD card RW)
BUFFALO (melco) HD-P40U2 (Portable HD)
BUFFALO (melco) HD-120IU2 (Outside HD)

CAMEDIA X250 (Digital camera)

CIMA LABORATORY KRDC256 (USB memory)

CREATIVE CNMVS4G, CMV2F5G (HDD audio player)
CREATIVE MuVo (Memory audio player)
CREATIVE MuVo2 FM 5GB
CREATIVE NOMAD MuVo2 4GB (Portable MP3 player)

COWON iAUDIO 4 512MB (Silicon audio)

EPSON PM-A900 (Printer)

ELECOM MF-FU2128AGT

gigabeat MEG200J (20GBHDD)

GreenHouse GH-CRSD2 (SD card RW)
GreenHouse GH-UFD256LT (USB memory)
GreenHouse 6in1 Card R/W GH-CRSP6

HAGIWARA SYS-COM HUD-256PJ (USB memory)

IO DATA EDC-128M, EDC-256M, EDM-32M, EDM-256M, USB-32ED2 (USB memory)
IO DATA USB-3BRW, CF32MB (SmartMedia and CompactFlash RW)
IO DATA EasyDisk Mate 256MB (USB1)
IO DATA HDA-iU80 (Outside HDD)
IO DATA HDP-U20P1 (FAT32, USB1.1)
IO DATA EDL-128M/B
IO DATA EDL-256M/C, EDL-256M/G, EDL-256M/P
IO DATA USBHDD (DXPX-U)

iriver HH300, 320 (HDD audio player)
iriver H10

iPod shuffle

KONICA MINOLTA DiMAGE Xt, A200, KD-500Z (Digital camera)
KONICA MINOLTA DiMAGE Z3 (Digital camera)

LEXAR JumpDrive (USB memory)

[動作確認済GT4対応USBメモリ一覧.txt]

LOAS CRW-6M02SL (Multiple card RW)
MINOLTA DiMAGE Xt (Digital camera)
NIKON COOLPIX 3700 Panasonicの256MB SD (Digital camera)
OHM USB FlashMemory FreeDrive 32MB
OTOMO Capsule (MP3 Player and USB memory)
OLYMPUS C-750UZ
OLYMPUS C-2040ZOOM (Digital camera)+IO DATA SM (64MB)
Panasonic LUMIX DMC-FZ1, FZ2, FX7 (Digital camera)
Panasonic BN-SDCGP3 (256M SDcard) (SD cardRW)
PENTAX Optio S50 (Digital camera)
Princeton Xiao Jr.2 PFU-2J/256 (256MB) (USB memory)
Princeton Geminett PFU-G/128 (USB memory)
PRETEC iDisk TINY 2.0 Luxury 1GB
PQI QIS-512
Rio SU10 (FlashMemory audio player)
Rio SU30 (MP3 audio player)
Rio Rio Carbon (HDD audio player)
RunDisk USB FlashDisk128M (USB memory)
SunDisk SDCZ4-128-J65 (USB memory)
SunDisk Cruzer Micro128MB (USB memory)
SunDisk Cruzer MINI 128MB (USB memory)
SANYO XACTI J1 (Digital camera)
SANWA SUPPLY ADR-61U2 SM32MB (Multiple card RW)
SONY Pocket Bit USM32D
SONY Pocket Bit USM64D
SONY Pocket Bit USM128D
SONY Pocket Bit USM256D
SONY Pocket Bit USM512E
SONY USM32D, 64D, 128D, 256A, 256D, 512E (USB memory)
SONY PSP, Memory Stick ProDuo256MB, ProDuo512MB
SONY HMP-A1 (HDD Multiple player)
SONY MSAC-US30 (Memory Stick RW)+PRODuo512MB
TOSHIBA U2A-512MT (USB memory)
TOSHIBA TransMemory U2B-128MT, U2A-256M
TOSHIBA IE|GIGABEAT MEG50JS
TOSHIBA gigabeat G5